



PU-CLEANER

Description

PU-Cleaner is used for cleaning PU-foam guns and removing uncured polyurethane foam.

Directions for use

Working directions gun cleaner:

After removing the empty foam can, screw the PU-Cleaner onto the adaptor. Pull the trigger several times in order to thoroughly flush the gun with the cleaner. Let the cleaner affect for a while and flush the gun again. After using the cleaner, clean and dry the screw thread of the adaptor. Smear Vaseline onto the upper side of the adaptor.

Working directions spray cleaner:

Place the activator onto the valve and press slightly in direction of the filthy spot. Let the cleaner affect for a while and remove the polyurethane with a cloth or paper.

Content of aerosol can:

150 ml and 500 ml

BOSTIK HOTLINE

Smart help +49 9366 9071-0



Our information sheets and other publications are intended to provide advice based on the best knowledge at our disposal. However, contents are not legally binding with regards to processing and application as these do not fall within our field influence. The right is reserved to make modifications in the interests of improvement or further development of the product.