

INSTRUCTION MANUAL

Mobile compact LED light

FL5000LMDCHIEU

IMPORTANT! RETAIN FOR FUTURE REFERENCE:
READ CAREFULLY!

Technical specifications

Protection class	III
Type of protection	IP65
Impact resistance	IK08
Operating temperature	-10°C ~ +40°C
Illuminant	50W, LED
Luminous flux	5000lm - 500lm (100%-10%)
USB output	5V 2A
Charger	12,6V 4A with 5 m cable
Charging time	Approx. 3.5 h
Operating time	Approx. 1.5 - 2 h (100%)
Battery	Li-ion 11.1 V; 2600 mAh
Dimensions	261 x 128 x 201 mm
Net weight	1500 g

Proper intended use

The LED light is suitable for indoor and outdoor lighting applications.
Press the on/off switch on the back.

Dimming range: 10% Power – 100% Power.

Low battery warning: the light will flash 4~6 times about 5 minutes before battery runs out.

Maintenance

Please note: for non-user replaceable light sources

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.
Never open the lamp when the mains supply cable is connected.

Cleaning

Do not use solvents, corrosive cleaners or the like. Use a dry or slightly moist cloth for cleaning **only**.



Safety information

1. Prior to commissioning, make sure the right voltage is available.
2. Prior to each charge, make sure the light and mains supply cable are not damaged in any way. Never use the lamp if you find damage.
3. Do not use the handlamp in explosive environments in which flammable liquids, gases or dusts are present. **Risk to life!**
4. LED lights are extremely bright. Do not look directly at the lamp.

Disposal

Dispose of electrical devices in an environmentally responsible manner!

Do not dispose of electrical devices with household rubbish. In accordance with European Directive 2012/19/EU regarding electrical and electronic devices must be collected separately and sent in for recycling. Please contact your local authorities for available disposal options for your worn-out device.



BME Group Sourcing B.V.
Walaardt Sacréstraat 405
1117BM Schiphol
The Netherlands

www.bme-group.com